





















Arriva 752

ordering guide

1. Select gas type (engine)		
	Arriva 752 engine NG	RHFE752ETRN
	Arriva 752 engine LPG	RHFE752ETRL
Supplied with the engine is the remote control and batteries, screw pack, cable tie, frame mounting screws, gas connection, and flue clamping bracket (for direct A/B flues).		
2. Select frame option		
 	Flat black frame Flat stainless steel frame	R2711* R2712*
 	Stainless on black frame Black on black frame	R2713** R2714**
 	Stainless on stainless frame Black on stainless frame	R2715** R2716**
* The flat frames are supplied as a single frame ** Supplied in two pieces—inner and outer frame		
3. Select burn media		
	Arriva 752 black pebbles	R2740
	Arriva 752 white quartz	R2741
4. Select flue components		
	Direct A flue kit (walls 115-240 mm)	R2731
	Direct B flue kit (walls 200-400 mm)	R2732
	Direct flue kit (walls up to 385 mm)	ASPDFK
	Adaption flue kit	ASPKIT03
	Vertical terminal (roof cowl)	ESROOFCOWL
	Flue pipe 900 mm	ESPIPE900
	Wall terminal kit	ESWTERM
	45 ° flue bends (two in a kit)	ESBEND
	Wall plate	ESPLATE
	Steel flue guard	R1370
	Condensate trap	ESCONDK
The condensate trap is included in the ASPKIT03. It only needs to be ordered separately if doing through-wall vertical flueing (not common).		